Project Report

1. Team Members:

• Name: Ahmed Wael Ibrahim

ID: 55-13512

Tutorial Number: T-24

Email: Ahmed.labib@student.guc.edu.eg

Contribution: implemented the Reliable Data Transfer Protocol V2.2 receiver side

• Name: Marwan Mostafa Elezaby

ID: 55-13999

Tutorial Number: T-24

Email: Marwan.elezaby@student.guc.edu.eg

Contribution: implemented the Reliable Data Transfer Protocol V2.2 sender side

• Name: Mohanad Yehia Abdelmoniem

ID: 55-19624


Tutorial Number: T-24

Email: Mohanad.abdelmoniem@student.guc.edu.eg

Contribution: Made the project report


2. FSM Diagram:

Sender FSM Diagram:



Receiver FSM Diagram:

RECEIVER SIDE



3. Pseudo-code:

RDT Sender Side Pseudo-code:

```
SenderProcess:
  - buffer: list()
  set outgoing data(buffer):
     buffer = buffer
  get outgoing data():
    return buffer
RDTSender:
  - sequence: string
  - net srv: RDTReceiver
  - clone: dictionary
  __init__(net srv):
    sequence = '0'
    net srv = net srv
  get checksum(data):
     if length of data is not 1:
       raise ValueError("Input must be a single character")
     checksum = ASCII value of data
    return checksum
  clone packet(packet):
     pkt clone = {
       'sequence number': packet['sequence number'],
       'data': packet['data'],
       'checksum': packet['checksum']
    return pkt clone
  is corrupted(reply):
     expected checksum = reply['checksum']
     actual checksum = ASCII code of clone['sequence number']
    return actual checksum is not equal to expected checksum
  is expected seq(reply, exp seq):
    return reply['ack'] is equal to exp seq
```

```
make pkt(seq, data, checksum):
    packet = {
       'sequence number': seq,
       'data': data,
      'checksum': checksum
    return packet
  rdt send(process buffer):
    for data in process buffer:
       checksum = get checksum(data)
      pkt = make pkt(sequence, data, checksum)
       clone = clone packet(pkt)
      while True:
         print("Sender: Sending packet - Sequence: {pkt['sequence number']}, Data:
{pkt['data']}, Checksum: {pkt['checksum']}")
         reply = net srv.udt send(pkt)
         print("Sender: Received packet - Sequence: {reply['ack']}, Checksum:
{reply['checksum']}")
         if not is corrupted(reply) and is expected seq(reply, sequence):
           sequence = '1' if sequence is '0' else '0'
           break
         else:
           print("Sender: Resending packet due to corruption or wrong sequence number.")
           pkt = make pkt(clone['sequence number'], clone['data'], clone['checksum'])
    print('Sender Done!')
```

RDT Receiver Side Pseudo-code:

```
ReceiverProcess:
- __buffer: list()

deliver_data(data):
    append data to __buffer

get_buffer():
    return buffer
```

```
RDTReceiver:
  - sequence: string
    init ():
     sequence = '0'
  is corrupted(packet):
     computed checksum = packet['checksum']
     expected checksum = get ASCII code(packet['data'])
     return computed checksum is not equal to expected checksum
  is expected seq(rcv pkt, exp seq):
    return rcv pkt['sequence number'] is equal to exp seq
  make reply pkt(seq, checksum):
     reply pkt = {
       'ack': seq,
       'checksum': checksum
    return reply pkt
  rdt rcv(rcv pkt):
     print("Receiver: Received packet - Sequence: {rcv pkt['sequence number']}, Data:
{rcv pkt['data']}, Checksum: {rcv pkt['checksum']}")
     if not is corrupted(rcv pkt) and is expected seq(rcv pkt, sequence):
       deliver data(rcv pkt['data'])
       reply pkt = make reply pkt(sequence, get ASCII code(sequence))
       sequence = '1' if sequence is '0' else '0'
       print(f'Receiver: Acknowledgment sent - Sequence: {reply pkt['ack']}, Checksum:
{reply pkt['checksum']}")
       return reply pkt
     if is corrupted(rcv pkt):
       print("Receiver: Packet ignored due to corruption.")
     if not is expected seq(rcv pkt, sequence):
       print("Receiver: Packet ignored due to wrong sequence number.")
     prev sequence = '0' if sequence is '1' else '1'
     reply pkt = make reply pkt(prev sequence, get ASCII_code(prev_sequence))
     return reply pkt
```

4. Changes to Skeleton Code:

- Modified 'is corrupted' Method in 'RDTReceiver' Class:
- Reason: Completed the implementation of the 'is_corrupted' method by comparing the computed checksum with the expected checksum derived from the received packet's data. This is essential for determining whether the received packet is corrupted or not.
- Updated `rdt_rcv` Method to include print statements in `RDTReceiver` Class:
- Reason: Added print statements in the 'rdt_rcv' method to provide information about the received packet, including its sequence number, data, and checksum. This enhances visibility and understanding of the receiver's operation.
- Updated `rdt_rcv` Method to include acknowledgment sequence update in `RDTReceiver` Class:
- Reason: Modified the 'rdt_rcv' method to update the sequence number in the receiver based on the received packet's sequence number. This ensures that the receiver keeps track of the expected sequence number for the next incoming packet.
- Modified "is_expected_seq" Method in "RDTReceiver" Class:
- Reason: The `is_expected_seq` method is modified to compare the sequence number in the received packet with the expected sequence to Check if the received reply from receiver has the expected sequence number.
- Adjusted the 'make_reply_pkt' method to use the correct sequence number in 'RDTReceiver' Class:
- Reason: In the 'rdt_rcv' method, when creating the reply packet, the 'make_reply_pkt' method is used with the correct sequence number. This ensures that the acknowledgment sent in the reply packet corresponds to the correct sequence.

- Added 'clone' Attribute in 'RDTSender' Class:
- Reason: Introduced a `clone` attribute to keep a copy of the outgoing packet. This is used to compare the received acknowledgment with the original packet to determine corruption and check for the expected sequence number.
- Modified 'get checksum' Method in 'RDTSender' Class:
- Reason: Implemented the `get_checksum` method to calculate the checksum of the outgoing data by calculating the ASCII code of the input character 'data'. It ensures that the sender can correctly compute the checksum for the data it sends.
- Modified `make_pkt` Method to use the clone's values in `RDTSender` Class:
- Reason: In the 'rdt_send' method, when resending a packet, the 'make_pkt' method is used with values from the clone to recreate the packet correctly.
- Modified 'is corrupted' Method in 'RDTSender' Class:
- Reason: Implemented the `is_corrupted` method to check if the received acknowledgment is corrupted. It compares the expected checksum with the actual checksum calculated from the data.
- Modified `is_expected_seq` Method in `RDTSender` Class:
- Reason: Updated the `is_expected_seq` method to check if the acknowledgment received from the receiver has the expected sequence number. This ensures that the sender can verify if the acknowledgment matches the sequence number it expects.
- Adjusted `rdt_send` Method in `RDTSender` Class:
- Reason: Modified the `rdt_send` method to include the necessary logic for handling acknowledgments. The sender now enters a loop, resending the packet until a correct acknowledgment is received. This ensures reliability in the face of corruption or incorrect sequence numbers.

5. Test Cases and Results:

• Test Case 1:

Input: msg='Test' rel=0.9 delay=0 debug=0
Screenshot:

```
Last login: Sat Nov 25 16:84:42 on ttys002

-/Desktop/Guc/Semester 5/Introduction to Communication Networks/Implemented code

) python3 main.py msg='Test' rel=0.9 delay=0 debug=0 {
    'msg': 'Test'. 'rel': '0.9', 'delay': '0', 'debug': '0'}
Sender is sending:Test
Senders Sending packet - Sequence: 0, Data: T, Checksum: 84
Receiver: Received packet - Sequence: 0, Data: T, Checksum: 84
Receiver: Received packet - Sequence: 0, Checksum: 48
Sender: Received packet - Sequence: 0, Checksum: 48
Sender: Sending packet - Sequence: 1, Data: e, Checksum: 101
Receiver: Received packet - Sequence: 1, Data: e, Checksum: 110
Receiver: Received packet - Sequence: 1, Checksum: 49
Sender: Received packet - Sequence: 1, Checksum: 49
Sender: Received packet - Sequence: 0, Data: s, Checksum: 115
Receiver: Received packet - Sequence: 0, Data: s, Checksum: 115
Receiver: Received packet - Sequence: 0, Checksum: 48
Sender: Received packet - Sequence: 0, Checksum: 48
Sender: Received packet - Sequence: 0, Checksum: 48
Sender: Received packet - Sequence: 1, Data: t, Checksum: 116
Receiver: Received packet - Sequence: 1, Data: t, Checksum: 116
Receiver: Received packet - Sequence: 1, Data: t, Checksum: 116
Receiver: Received packet - Sequence: 1, Data: t, Checksum: 49
Sender: Received packet - Sequence: 1, Checksum: 49
Send
```

• Test Case 2:

Input: msg='Test' rel=0.7 delay=0 debug=0
Screenshot:

```
-/Desktop/Guc/Semester 5/Introduction to Communcation Networks/Implemented code

| python3 main.py msg='Test' ral=0.7 delay=0 debug=0
{ 'msg': 'Test': 'rel': '0.7', 'delay': '0', 'debug': '0',
| Sender is sending:Test
| Sender: Sending packet - Sequence: 0, Data: T, Checksum: 84
| Receiver: Received packet - Sequence: 0, Data: T, Checksum: 84
| Receiver: Acknowledgment sent - Sequence: 0, Checksum: 88
| Sender: Received packet - Sequence: 0, Checksum: 48
| Sender: Received packet - Sequence: 1, Data: e, Checksum: 101
| Receiver: Received packet - Sequence: 1, Data: e, Checksum: 197
| Receiver: Received packet - Sequence: 1, Data: e, Checksum: 49
| Sender: Received packet - Sequence: 1, Checksum: 49
| Sender: Received packet - Sequence: 1, Data: e, Checksum: 101
| Receiver: Received packet - Sequence: 1, Data: e, Checksum: 101
| Receiver: Received packet - Sequence: 1, Data: e, Checksum: 101
| Receiver: Received packet - Sequence: 1, Data: e, Checksum: 101
| Receiver: Received packet - Sequence: 0, Data: s, Checksum: 15
| Receiver: Received packet - Sequence: 0, Data: s, Checksum: 15
| Receiver: Received packet - Sequence: 0, Data: s, Checksum: 15
| Receiver: Received packet - Sequence: 0, Checksum: 2
| Sender: Received packet - Sequence: 0, Checksum: 2
| Sender: Received packet - Sequence: 0, Checksum: 15
| Receiver: Received packet - Sequence: 0, Checksum: 16
| Receiver: Received packet - Sequence: 0, Checksum: 48
| Sender: Received packet - Sequence: 0, Checksum: 48
| Sender: Received packet - Sequence: 0, Checksum: 49
| Sender: Received packet - Sequence: 0, Checksum: 49
| Sender: Received packet - Sequence: 1, Data: 1, Checksum: 116
| Receiver: Received packet - Sequence: 1, Data: 1, Checksum: 16
| Receiver: Received packet - Sequence: 1, Data: 1, Checksum: 16
| Receiver: Received packet - Sequence: 1, Checksum: 49
| Sender: Received packet - Sequence: 1, Checksum: 49
| Sender: Received packet - Sequence: 1, Checksum: 49
| Sender: Received packet - Sequence: 1, Checksum: 49
| Sender: Received packet - Seque
```

• Test Case 3:

Input: msg='Test' rel=0.2 delay=0 debug=0
Screenshots:

```
noter: Resending packet due to corruption of eveng augunts number.

colver: Received packet — Sequence: 0, Date: 0, Checksus du

colver: Packet ignored due to corruption.

colver: Packet ignored due to corruption our con-

colver: Packet ignored due to corruption our con-

colver: Received packet — Sequence: 0, Date: 0, Checksus: 155

colver: Received packet — Sequence: 1, Checksus: 125

colver: Received packet — Sequence: 1, Checksus: 1

colver: Received packet — Sequence: 1, Checksus: 1

colver: Received packet — Sequence: 1, Checksus: 1

colver: Received packet — Sequence: 2, Date: 0, Checksus: 1

colver: Received packet — Sequence: 3, Checksus: 1

colver: Received packet — Sequence: 3, Checksus: 1

colver: Received packet — Sequence: 2, Date: 0, Checksus: 1

colver: Received packet — Sequence: 3, Checksus: 4

colver: Received packet — Sequence: 3, Checksus: 4

colver: Received packet — Sequence: 4, Checksus: 4

colver: Accordance packet — Sequence: 4, Checksus: 4

colver: Accordance packet — Sequence: 4, Checksus: 4

colver: Received packet — Sequence: 4, Checksus: 4

colver: Checksus: 4, Checks
```

```
Sendor: Sectived packet - Sequence: 1, Checkman: 7

Rectiver: Rectived packet - Section of the service sequence number.
Rectiver: Rectived packet - Section of the service sequence number.
Rectiver: Rectived packet - Sequence: 2, Date: 1, Checkman: 135

Sendor: Rectiver: Rectived packet - Sequence: 2, Date: 1, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 3, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 3, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 3, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 3, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 3, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 4, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 4, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 5, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 6, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 6, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 6, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 6, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 6, Checkman: 136

Sendor: Rectiver: Rectived packet - Sequence: 6, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 7, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 7, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 7, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 8, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 1, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 1, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 1, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 1, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 1, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 1, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 1, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 1, Checkman: 136

Sendor: Rectiver: Rective packet - Sequence: 1, Checkman: 136

Sendo
```